


- 4. REMOVE ANY BURRS AND/OR SHARP EDGES.
- 3. REFER TO TORQUE WI FOR PROPER TORQUE VALUES.
- 2. REFER TO THE ASSEMBLY BOMS FOR ACURATE PART SELECTION.
- 1. THIS LAYOUT DRAWING IS FOR VISUAL REFERENCE ONLY.

**i5Com**  
**PROPRIETARY**  
**INFORMATION**

THIRD ANGLE PROJECTION  
  
 3D MODEL FILE: STEP

SCALE: NONE  
 REF #:  
 SIZE: A3

TITLE:  
**iMR350 GENERAL DIMENSIONS**

SHEET  
 1 OF 1

DESCRIPTION	DRAWN	CHK'D	DATE	REV
INITIAL DESIGN	M.V	R.M	2021-07-07	000

DWG NO. **iMR350**